


## **Delta™ Parts List**



SCHEMATIC#	DESCRIPTION	SKU#	SCHEMATIC#	DESCRIPTION	SKU#
1	Tank Adapter	17044	36	Internal Valve O-Ring	19425
2	Expansion Chamber Plug		37	Rear Bolt & External Valve O-Ring	19426
3	Delta Name Plate		38	Shock Absorber O-Ring	19427
4	Lower Grip Nut	19383	39	45 Rubber Grip	19429
5	Power tube		40	Grip Screws	19430
6	Ball Detent	19386	41	Gas Line	19435
7	Cup Seal	19387	42	Trigger Plate Dowel Pins	19436
8	Left upper Receiver	19388	43	Long Tank Adapter Bolt	19439
9	Bolt Plug	19389	44	Short Tank Adapter Bolt	19440
10	Barrel Adapter	19391	45	Valve Snap Ring	19442
11	Valve Body		46	Trigger Guard Screw	19443
12	Internal valve seat	19393	47	Internal Valve Spring	19444
13	Plunger Cup	19394	48	Bolt Handle Rubber Cover	19445
14	Rear Valve Seat	19395	49	Trigger Return Spring	19446
15	Single Trigger Assembly	19396	50	Drive Spring	19447
16	Left Lower Receiver	19397	51	Drive Spring Guide	19448
17	Trigger Guard		52	Sear Spring	19449
18	Lower Receiver Acorn Nut	19400	53	Barrel Adapter O-Ring	19452
19	Lower Receiver Screw	19401	54	Bolt handle	19454
20	Trigger Plate	19402	55	Rear Bolt	19455
21	Trigger Plate Spacer	19404	56	Front Sight Rail	20169
22	Sear		57	Magazine Retention Screws	
23	Right Upper Receiver	19406	58	Magazine Holder Nut	
24	Safety with O-rings	19407	59	Delta Barrel Assembly	20190
25	Front Bolt	19409	60	Magazine Assembly	20191
26	Linkage Arm	19410	61	Magazine Locking Arm	
27	Long Receiver Bolt	19413	62	Stock Assembly	20195
28	Short Receiver Bolt	19414	63	Rear Sight Rail Assembly	
29	Receiver Nuts		64	Valve Stem	
30	Valve Screw	19416	not shown	Complete Valve	19382
31	Right Lower Receiver	19417			
32	Velocity Screw	19418			
33	Grip Upper Hex	19419			
34	Tank Adapter Nuts	19423			
35	Front Bolt O-Ring	19424			